

# INSTALLATION INSTRUCTIONS

ONKI AEGIS CENTER GUARD – PART # 533522A  
02-06 JEEP Liberty

**Parts List** *(Please check that you have all the parts listed below before you start installing)*

Quantity	Center guard installation hardware
2	Mounting brackets
8	M12X40 (19mm hex head bolts)
8	M12 Nylon lock nuts (19mm socket nuts)
12	½" SAE washers

## Installation of Mounting Frame Brackets & Center Guard

1. Remove 2 nuts and 1 bolt that are fastening the tow hooks to the vehicle's frame.



2. Remove the tow hooks and set aside for reinstallation.
3. Identify the driver side and passenger side brackets marked D for driver and P for passenger.
4. Install the brackets on the original location of the tow hooks. Place the tow hooks under the brackets then fasten down using the original nuts and bolts.
5. With the help of another person, center the guard on the vehicle and fasten to the brackets using the supplied hex head bolts and self locking nuts.
6. Make sure that all nuts, bolts, and brackets are tightened.