



2005-2013 C6 CORVETTE CONCEPT SMD SIDEMARKERS INSTALLATION INSTRUCTIONS

PART #3150



FRONT: Tools needed

- First, make room by turning the wheel in the opposite direction.
- Locate the tabs holding the fender well coverings in place.
- Remove these with a flathead screwdriver.
- Now you can gently pull the bumper away from the fender.
- This should expose access to the front sidemarker.



SIDEMARKER: Tools needed

- Depress tab to release the sidemarker with flathead screwdriver.
- With the marker released, you can now unplug the harness.
- Now plug in the new ORACLE Concept LED Sidemarker.
- The sidemarker should snap right into place and fit flush.
- Test by turning the headlight switch to parking light position.



REAR: Tools needed



- Move to the rear of the vehicle.
- Locate the bumper retainer screw in the rear well.
- Using a 9/32" socket, remove this screw.
- Now you can gently pull the bumper away from the fender.
- This should expose access to the rear sidemarker.



Check out the collection of custom and factory signal lights we offer.