



Information for BMW E46 M3 OS Giken Super Lock LSD or TCD (BMW-L1) Installation

For your OS GIKEN Super Lock LSD or TCD (BMW-L1) installation to BMW E46 M3, you need 2 x BMW OEM side flanges from BMW E36 M3C 3.2-liter model (OEM Side Flange # 33 13 1 214 087).

If the above mentioned side flanges are not available, then you need to modify originally equipped BMW OEM side flanges from BMW E46 M3.

Please re-use originally equipped longer side flange from E46 M3 (OEM Side Flange # 33 13 7 840 563). You do not need originally equipped shorter side flange for the installation. Please purchase an additional OEM longer side flange (# 33 13 7 840 563) to replace the shorter side flange.

The both longer side flanges are needed to be shortened to 78.8mm as shown in the picture 1 below.



(Picture 1)

- ※ Please be aware of potential risks and hazards when installing our products. We do not take any responsibility for any loss and/or injury occurred when our products are modified, re-used and/or ill-fitted. We do not take any responsibility for any loss and/or injury that resulted from the failure in following instructions given on this sheet.
- ※ All information on this manual is collected from BMW E46 M3 sold in Japan, and it may not be applicable to the vehicles sold in your country.
- ※ Specifications may be changed without notice.