



**2015 Colorado/ Canyon
IN 596**

Product No.
10-1304

Tools Required

- 1/2" Socket
- 1/2" Wrench
- 3/8" Nut driver on Drill

Hardware Included

- [BRACKETS](#) SHOW ON RIGHT
- 1- BOLT PACK

Torque Specification:

- 1/4" Bolts - 6 Ft Lbs.
- 5/16" Bolts - 19 Ft Lbs.

Locate Driver and Passenger Bracket Locations

Measuring from the front wheel well back, mark the following locations on the pinch weld. There will be factory holes in line with these marks that will be

DRIVER

- LOCATION 1: 13"
- LOCATION 2: 76 1/2"

PASSENGER

- LOCATION 1: 13"
- LOCATION 2: 75 1/4"

5/16" Spring Clip **FL567**
4 PCS



At each of the measurements above remove the rubber plug in the holes and slide 5/16" spring clips supplied in bolt package into the larger hole slide toward the smaller hole until clip snaps into position.

Once all spring clips are mounted into position. Place the FL567 bracket up to the inside rocker panel and thread 5/16" x 3/4" bolts into the spring clips. Make sure brackets are onto the vehicle straight before tighten bolts.

Repeat in all 4 locations.

