

DODGE DUALY MUD FLAP INSTALLATION INSTRUCTION 1994-C

READ ENTIRE INSTRUCTION SHEET BEFORE INSTALLING MUD FLAPS TO ENSURE A PROPER INSTALLATION.

STEP 1. USING THE 5/16 x 1" BOLTS, NUTS, FLAT WASHERS AND LOCK WASHERS FASTEN THE RUBBER FLAP TO THE BRACKET AS SHOWN.

STEP 2. POSITION THE FLAP TO DESIRED LOCATION ON THE VEHICLE

STEP 3. USING 5/16 x 1" BOLT, NUTS, LOCK WASHERS FASTEN THE BRACKET TO THE INSIDE OF THE WHEEL WELL USING THE SLOTS FOR HEIGHT ADJUSTMENT. MARK AND PRE-DRILL HOLES WITH A 1 1/32" DRILL BIT.

NOTE: BOLTS MUST BE FASTENED TO THE INNER WHEEL WELL LIP SO BOLTS DO NOT PENETRATE INTO THE BED OF THE TRUCK.
SEE ILLUSTRATION.

STEP 4. USING THE 1/4 x 1" TEK SCREW FASTEN THE BRACKET TO THE MIDDLE WHEEL WELL LIP AS SHOWN.

