

04-CUR. SPRINTER VANS DRILLING INTO THE BODY IS REQUIRED

OTY DESCRIPTION NOTALIATION PARTS LIST:

RUNNING BOARD 1 DRIVER & 1 PASSENGER 2

STONE GUARD 2 LEFT & 2 RIGHT

3/8°x1 SELF TAPPING SCREW

24 \$14x3/4" TEK SCREW 12 1/4x5/8" SQUARE HEAD SCREW

12 1/4-20 HEX NUT


HORIZONTAL BRACKET, SUPPORT, 3124F 6


5/16"x 3/4" BOLT

5/16-18 HEX WASHER HEAD NUT 24

FLAT BRACKET, FL100 2 FENDER BRACE BT46

BENT TAB ASO1





BRACKET ASSEMBLY MOUNT TO BODY PREDRILL A 5/16" HOLE THROUGH THE PINCH WELD. ATTACH FL100 BRACKET TO THE BODY WITH 5/16" BOLT AND NUT, LOOSLY TIGHTEN. ATTACH THE ASO1 BENT TAB TO THE BODY PANEL WITH A \$14x 3/4" SELF DRILLING SCREW.

