




30816 HB5 Series Bulb Headlight Relay Conversion Harness Installation Instructions

1. Disconnect the battery.
2. Mount the fuses and relays in a suitable location away from the exhaust manifolds, between the battery or battery source and headlights. Self tapping screws are supplied in this kit for mounting the relays and fuses.
3. Route the Red Power wire to the POSITIVE side of the battery or a 12 VOLT battery source and cut to length. Terminate the Red wire with the appropriate ring terminal (supplied in kit) and make the connection.
4. Route the Black Ground wire to the NEGATIVE side of the battery or a known good GROUND and cut to length. Terminate the Black wire with the appropriate ring terminal (supplied in kit) and make the connection.
5. Unplug the old headlight connectors from the headlight bulbs; refer to your owner's manual for headlight removal for your specific vehicle.

NOTE: Any new harness wire may be cut to length for proper fit.


7. Using the diagrams on the back of this page splice the new headlight wires into factory headlight wires according to the type of bulb you are using.
8. The left over old headlight connector will not be used. Tape and store it out of the way.
9. Turn on headlights and check for proper operation.

**BULB TYPE
9004**



**A-BLACK
B-TAN
C-LT.GREEN
CONNECTOR PINOUT**

**BULB TYPE
9007**



**A-TAN
B-BLACK
C-LT.GREEN
CONNECTOR PINOUT**

