

PERRIN

Kit Includes:

- (1) Sensor Adapter
- (1) Port Plug
- (1) Rubber O-ring (installed)
- (2) Filter mounting nuts - M20 x 1.5 & 3/4"

Remove the factory oil filter. Slide sensor adapter with O-ring onto oil filter mount. (O-ring between block and adapter) Attach with appropriate mounting nut. Using a 26mm wrench, tighten to 20 ft/lbs. Attach oil filter onto new mounting nut. Make sure the oil filter is completely seated and all sensor adapter ports are filled with either the supplied bung or a gauge sensor and are tightly secured.

