

PERRIN

2015+ WRX/STI Firewall Grommet

Parts Included with PERRIN Firewall Grommet:

- (1) PERRIN Firewall Plug for 2015 WRX/STI

Installation Instructions:

- 1) For 2015 WRX models:
 - A. Using picture below, locate engine bay firewall plug on right side of vehicle. **NOTE: On CVT models, this plug is located behind the black colored firewall cover.**
 - B. Remove plug from car.
 - C. Skip to Step 3.



Above picture shows both engine bay firewall plug (right side of picture) and second plug located behind plastic windshield wiper cover (left side of picture).

- 2) For 2015 STI models:
 - A. An aftermarket intake system or removal of "sound generator pipe" is required before proceeding.
 - B. Using picture below, locate grey plastic nipple with rubber grommet on firewall on right side of vehicle.
 - C. Pull grey connector through firewall and remove from hose.
 - D. Remove rubber grommet from car.



Above picture shows both engine bay firewall grommet (right side of picture) and grommet located behind plastic windshield wiper cover (left side of picture).

- 3) Locate plastic cover below window (covers windshield wiper motors) and remove the first 3 clips starting from right side. **NOTE: First connector is a Philips head fastener, and the following are (2) plastic push button type connectors. The last 2 push button type connectors can easily break off during removal. Take extreme caution and be prepared to replace them.**
- 4) Locate small plastic cover on right side of window and fender and unclip from fender and window. **NOTE: It is not necessary to remove this to move on to next step.**
- 5) Lift up and pull forward on plastic cover to expose secondary hole on firewall.
 - A. For WRX models you will find a rubber plug that you can remove and replace with an additional PERRIN Firewall Grommet, or you can simply create a slit to pass wires through.
 - B. For STI models you will find the remaining portion of the sound generator pipe. Remove this rubber pipe and plastic fitting from hole in firewall. Either leave OEM rubber surround in place or install an additional PERRIN Firewall Grommet.
- 6) Squeeze PERRIN grommet and place into hole in firewall. Spin plug in hole until it is fully seated against firewall.
- 7) Using a sharp knife (like an X-Acto knife), cut through plug using cross-hair marks as a guide.
- 8) Install desired wires and hoses through plug and route through to the inside of the car. **Note: Using a multi-pronged grabber tool to push wires through and to the inside of car is highly recommended.**
- 9) Reinstall plastic cover and fittings to secure back to chassis. **Note: Replace any broken fittings at this time.**
- 10) Once wires/hoses are routed, use a zip tie to secure wires in PERRIN Firewall Grommet.