

# PERRIN

## PERFORMANCE

### Pitch Stop Mount

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation.

#### SPECIAL NOTES:

- Expect some added NVH during certain situations like decelerating, and during start up.

#### Included Parts with PERRIN Pitch Stop Mount:

- (1) PERRIN Pitch Stop Mount
- (1) Grease Packet

#### Installation Instructions

1. If top mounted intercooler is installed, remove Intercooler from chassis following the factory service manual. If front mounted intercooler is installed, you may be able to leave boost tubes in place to install PERRIN Pitch Stop Mount.
2. Remove 14mm nut and bolt from transmission, and rear 14mm bolt from fire wall. Remove OEM pitch stop mount.
3. Apply a small amount of grease to both sides of bushings, then install PERRIN Pitch Stop Mount to transmission and fire wall.
4. Tighten front nut and bolt to 37ft-lbs and rear bolt to 43ft-lbs.
5. If Intercooler was removed previously, reinstall following factory service manual.

