

PERRIN

02A 07 WRX/STI RADIATOR SHROUD

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation.

Parts Included with the PERRIN Radiator Shroud:

- (1) PERRIN Aluminum Radiator Shroud

INSTALLATION

- 1) Locate and remove (2) 10mm bolts securing OEM intake scoop to car.
- 2) Locate and remove upper radiator brackets (2) 12mm bolts. One on each side of radiator.
- 3) Set PERRIN Radiator shroud onto car.
- 4) Reinstall OEM radiator support brackets, and tighten to 12ft-lbs. Some minor adjustment may be necessary to clear hood release bracket.
- 5) Reinstall OEM intake hood scoop and tighten bolts to 12ft-lbs.
- 6) Locate and remove short rubber trim mounted to hood directly over OEM intake scoop. If this piece is left in place, it can cause wear marks on the shroud.
- 7) Take car for test drive. You will know your radiator shroud is installed properly if your friends are envious of your engine bay when hood is lifted.