

PERRIN

08-14 WRX/STI RADIATOR SHROUD

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation.

Parts Included with the PERRIN Radiator Shroud:

- (1) PERRIN Aluminum Radiator Shroud

INSTALLATION

- 1) Locate and remove (2) plastic push screws securing OEM intake scoop to car. Take care as these can be stripped easily.
- 2) Locate and remove (4) plastic pop-its connectors holding upper part of grill to radiator support.
- 3) Locate and remove upper radiator brackets (2) 12mm bolts. One on each side of radiator.
- 4) Set PERRIN Radiator shroud onto car and reinstall (4) plastic pop-it connectors.
- 5) Reinstall OEM radiator support brackets, and tighten to 12ft-lbs. Some minor adjustment may be necessary to get all plastic fittings to line up.
- 6) Take plastic push screws and remove screw from body. Install intake hood scoop and push bodies of push screws through chassis. Finally push screws through body to secure.
- 7) Locate and remove short rubber trim mounted to hood directly over OEM intake scoop. If this piece is left in place, it can cause wear marks on the shroud.
- 8) Take car for test drive. You will know your radiator shroud is installed properly if your friends are envious of your engine bay when hood is lifted.