

PERRIN

PERFORMANCE

08+ WRX Upper Radiator Stay Kit

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation.

Parts Included with the PERRIN Radiator Stay Kit:

- **(2) PERRIN Radiator Stay**
- **(2) M8 Flat Head Bolts**

INSTALLATION

- 1) Raise hood and locate (2) upper radiator stays located above radiator.
- 2) Remove 12mm bolts securing them to radiator support beam/core support.
- 3) Remove rubber bushing from each OEM radiator stay. **NOTE: A small amount of lube will help remove these.**
- 4) Install rubber bushings into PERRIN Radiator stays making sure to put thicker part on bottom (away from logo).
- 5) Using supplied M8 hardware, install screws through PERRIN Radiator Stays and tighten to 12-15ft-lbs. (some adjustment may be necessary to align brackets to car).