



INSTALLATION INSTRUCTIONS

Winch Fairlead Mount

IMPORTANT: Thank you for purchasing this Poison Spyder product. Please read through this entire document before proceeding with installation. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping.

APPLICATIONS

These installation instructions apply to the following Poison Spyder products:



45-57-010 Winch Fairlead Mount

PARTS LIST

Please check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping.

(1) Winch Fairlead Mount

TOOLS NEEDED

- Wrenches (to fit the existing hardware of your winch and fairlead)

INSTALLATION NOTES

VERY IMPORTANT: Read and follow your winch manufacturer's Owners Manual and Operating Instructions prior to operating your winch. Follow all safety precautions during any operation of your winch.

- **Before you begin, park** the vehicle in a suitable workspace and set the parking brake.
- **The Poison Spyder Customs Winch Fairlead Mount** is designed to work with bumpers and winch mounts that do not already have an integrated fairlead mount.
- **The Winch Fairlead Mount** comes powdercoated black. Be careful to protect the powdercoat finish during installation. If you wish to paint the mount a different color,

scuff the powdercoat with sandpaper then apply primer followed by the color of your choice.

- **Install the Winch Fairlead Mount** BETWEEN the winch and the bumper or winch plate. You may need longer bolts (not included) to secure the winch to the bumper or winch plate, to compensate for the thickness of the Winch Fairlead Mount.
- **The Winch Fairlead Mount** is designed to fit the 10" x 4-1/2" bolt pattern common to most Warn winches except 8274. Many other winch brands use the same bolt pattern.
- **The Winch Fairlead Mount** is designed to fit the winch rope slot and 10" bolt pattern of most Warn or common aftermarket roller or Hawse fairleads, including the Poison Spyder Aluminum Hawse Winch Fairlead (P/N 45-45-010). Install your fairlead according to the fairlead manufacturer's instructions.
- **The winch bolt holes** in the bottom plate of the Winch Fairlead Mount are slotted front-to-back to allow for adjustment of the fairlead and mount forward or backward. On some Poison Spyder bumpers with shackle tabs and brawler bars or stingers, it may be necessary to adjust the fairlead (and mount) further back in order to facilitate easily installing and removing recovery shackles from the shackle tabs. Test for this and make any necessary adjustments before final tightening of the winch mount bolts.