



INSTALLATION INSTRUCTIONS

Model **PL2450 & PL2450C**
2012-2019 Ford Euro Ranger T6
2012-2019 Mazda BT-50

Package Contents: Handle Assembly, 2 Keys
Instructions

Tools Required: 10mm Wrench

Step 1: Remove the screws from the inside of the tailgate that hold the access panel in place. Remove the access panel.

Step 2: Remove the two bolts that hold the factory handle into the tailgate. Hold the handle in place to prevent the handle from falling out.
-Remove the factory handle from the tailgate.

Step 3: Install the Pop and Lock handle assembly into the tailgate. Start by inserting the top of the handle into the tailgate first and rocking the bottom into place. The bottom of the handle has to be fully inserted. Due to the lock assembly this is a tight fit. The long tab on the bottom of the handle has to snap past the sheet metal into the tailgate.
-Reinstall the two mounting bolts and tighten.
Do not install the access panel yet.



Step 4: - Shut the tailgate. Test the function of the lock. Turn the key counter clockwise to unlock. Turn the key clockwise to lock. If everything works reinstall the access panel.