



Installation Instructions

Model RVGC- ADJ



Model RVGC-ADJ 03/15



Model Number RVGC-ADJ
Gross Trailer Weight : 24,000 lbs
Gross Trailer Tongue Weight : 6,500 lbs

INSTALLATION PROCEDURE

WARNING: Verify adequate trailer swing clearance between trailer nose and cab of truck.

1. Simply remove your existing king pin box and install the RVGC-ADJ back in the same location on your camper.
2. Attach the angled "L" bracket on the outside of the unit behind one of the bolts that attach the RVGC-ADJ to the camper.
3. **Torque Pin Box Fastners to 120 ft pounds.**
4. Place the pull cable thru the slot in the angled "L" bracket and run it to the round hole in the end of the coupler handle and attach with the provided 3/8" X 1" Hex Bolt and Nut.
5. To adjust height simply loosen the 1/2" X1" set bolt in the back of the down tube. Then remove the 3/4" X 5" Bent Pin with keeper. Move lower portion to desired position, Re-Install Bent Pin with keeper and tighten set bolt.

Hardware Provided

- 1pcs- 1/2"-X1" Set bolt
- 1pcs- 1/2" Nut
- 1pcs- 3/4" X 5" Bent pin with keeper
- 1pcs- 3/8" X 1" Hex Bolt
- 1pcs- 3/8" Lock Nut
- 1pcs- "L" Bracket cable Guide
- 1pcs- Pull Cable with Handle



MADE IN

U. S. A.

d T T T