



Model RVGC 03/15



Model Number RVGC-Cushioned
Gross Trailer Weight : 24,000 lbs
Gross Trailer Tongue Weight : 6,500 lbs

INSTALLATION PROCEDURE

WARNING: Verify adequate trailer swing clearance between trailer nose and cab of truck.

1. Simply remove your existing king pin box and install the cushioned RVGC back in the same location on your camper.
2. Attach the angled "L" bracket on the outside of the unit behind one of the bolts that attach the RVGC to the camper.
3. **Torque Pin Box Fastners to 120 ft. lbs.**
4. Place the pull cable thru the slot in the angled "L" bracket and run it to the round hole in the end of the coupler handle and attach with the provided 3/8" X 1" Hex Bolt and Nut.
5. To adjust height simply loosen the 1/2" X1" set bolt in the back of the down tube. Then remove the two bolts on either side of the "Lock Collar". Next remove the lock collar, move lower portion to desired position, Re-Install the lock collar and tighten the two bolts on either side and tighten the set bolt.

Hardware Provided

- 1pcs- 1/2"-X1" Set bolt
- 1pcs- 1/2" Nut
- 1pcs- 3/8" X 1" Hex Bolt
- 1pcs- 3/8" Lock Nut
- 1pcs- "L" Bracket cable Guide
- 1pcs- Pull Cable with Handle

