

# INSTRUCTION SHEET

## JEEP XSTORQUE STARTERS

### ELECTRICAL WIRING INSTRUCTIONS

1. Install a jumper wire from the “Bat” terminal connection on the starter solenoid to the “IGN” terminal.

[OPTIONAL: Run the “switch” wire from the starter relay to the “IGN” terminal on the starter solenoid.]



2. Connect the positive battery wire to the “BAT” terminal on the starter solenoid.

