



INSTALLATION INSTRUCTIONS
Progress Technology Anti-Sway Bar
2008 > Mitsubishi Lancer (Rear) 62.1431

NOTE: Progress Technology products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components. Please read instructions from start to finish and verify the parts in the parts list before beginning installation.

Parts List

<u>Item</u>	<u>Quantity</u>
Anti-sway bar (22 mm)	1
Bushings	2
Bushing brackets	2
Washers	4
Lube	1
Instruction Sheet	1

1. Park vehicle on a smooth, level asphalt or concrete surface. Block front wheels. Jack up rear end of car and support with jack stands.
2. Remove the two sheet metal braces from under the chassis. Remove the nuts that hold the end links to the bar. Next, remove the factory bushings and brackets, keeping the hardware. Remove the bar from the vehicle.
3. Locate the pivot "D" shaped polyurethane bushing and tube of special grease supplied in the hardware kit. Cut the end off the tube and apply grease to the bore of the bushing. Open bushing and snap them over the new sway bar, as positioned on the stock bar.
4. Place the new brackets (supplied) over the bushings. Use washers provided on the OE hardware and torque bushing bracket to OE specifications. Next, fasten end links to the bar and torque to OE specifications. Attach the rear braces to the chassis.
5. **THIS IS AN ADJUSTABLE SWAY BAR. The hole toward the end of the bar is the softest setting. Handling characteristics of the vehicle have changed. Use caution when test driving.**
6. Installation is complete. Check assembly periodically for tightness.