

Installing the PSC upgraded steering gear in place of your stock TJ gear will require shortening of the steering shaft. This is easily accomplished by removing the plastic pin that joins the two halves of the telescoping shaft. A hand-held drill works well for this.

