



# ISR Series SuperGlide Foot Kit Installation

(Part #2708 & #2911 Low Profile)

As of July 2014, #2700 and #2900 ISR SuperGlide hitches are shipped with ISR foot kit #2708, and the #2300 ISR HD SuperGlide hitch is shipped with ISR Low Profile Foot Kit #2911 already installed. For those vehicles with extra high ground clearance, it may be necessary to replace a #2708 Kit with the #2911 Low Profile Foot Kit.

**NOTE:** Before proceeding, read your ISR Series SuperGlide Owner's Manual completely, verifying base hole locations in the "Base Rail Foot Assembly" section as it relates to your truck and trailer.

1. To swap out Foot Kits, simply remove and discard the old hardware, and reinstall the new Hitch Feet with the *new* hardware provided.

**IMPORTANT:** Both Foot Kits use the same hardware, but *must be replaced with new hardware* when a new or replacement Foot Kit is ordered.

2. Torque the 1/2" bolts to 75 foot pounds.

**NOTE:** Hitch pins and clips are pictured (*top right*) as fully assembled, but are *not* replaced when swapping out Foot Kits.

