



MorRyde Installation Instructions

1. Remove the four 9/16-12" bolts with a 13/16 socket.
2. Push restraining rods toward center of box.
3. Slide spacer blocks into channel.
4. Install bolt through hole.
5. Install and tighten nut (self locker) x 4.
6. Slide PullRite skid pad (making sure wedge is to rear of box) into place.
7. Put plate in location using two 9/16-12" bolts opposite corners to hold plate.
8. Align opposite corners to restraining rods.
9. Align all 4 bolts before tightening.
10. Tighten all 4 bolts and torque to 85 ft. lbs.
11. Photo 11 shows a completed installation

