

***Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.***

<b>Parts List</b>	
<b>Description</b>	<b>Qty</b>
Diamond Donut (P/N # 175)	2
Foam Gasket	2
9/16" Bolt	2
Flat Washer	2
5/32" Set Screw	2

<b>Tools Needed for Installation</b>
9/16" Socket & Ratchet
5/32" Allen Wrench
7/16" Drill Bit
Drill
Tape Measure

**Step 1:** Measure from center of stake pocket hole to toolbox, subtract 5/8 inch.

**Step 2:** Transfer measurements to bed rail, starting at the center of hole in pad.

**<<NOTE: MEASURE TWICE, CUT ONCE. >>**

**Step 3:** While holding Diamond Donut at appropriate place on toolbox, mark toolbox with a nail thru the center of donut. Drill 7/16" hole in the toolbox.

**Step 4:** Place the gasket between donut and the toolbox.

**Step 5:** Mount both donuts with the set screw facing 4 and 8 positions of a clock.

**Step 6:** Be sure set screws are not blocking groove.

**Step 7:** Install bed rails in the donuts and then fasten pads to rear stake pocket holes.

**Step 8:** Tighten set screws in Diamond Donuts.

**Step 9:** Verify all hardware is tight to complete the assembly.

