

**Please read all instructions before installation and to check to see that all parts are included.**

**Step 1:** Separate the parts and make sure that you have all the parts shown in **Figure 1** for each Push Up Tie Down.

**Step 2:** Assemble the Push Up Tie Down, gasket, expanders and threaded plates as shown in **Figure 2**. Make sure that the expanders are as far down on the bolt as possible. **NOTE:** You may need to compress the expander block slightly to fit the shorter bolt.

**NOTE:** The rubber mounting blocks may need to be trimmed to fit some of the smaller stake pocket holes, such as Ford and 88-98 Chevy/GMC.

**Step 3:** Insert the complete assembly into the stake pocket. **NOTE:** One bolt has been left long so that you can angle the assembly into the hole on smaller stake pockets.

**Step 4:** Make sure the Push Up Tie Down is centered and tighten the bolts so that the expanders flare out and grip the sides of the pockets as shown in **Figure 3**. **DO NOT OVER TIGHTEN** as this may cause the side rail to deform.

---

**NOTE:** PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new Push Up Tie Downs.

---

