

## **Super Duty Boss Grille Installation Instructions**

Congratulations on your purchase of a high quality PUTCO product.

## Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty.
Boss Grille (Lighted or Non Lighted)	1
Bottom Bracket	1
Top Right Bracket	1
Top Middle Bracket	1
Top Left Bracket	1
¼"-20 x ¾" Bolts	10
¼"-20 Lock Nut	10
¼"-20 Flat Washer	20

## **Tools Needed:**

- 10mm Wrench
- 7/16" Wrench / Socket
- Flat Head Screw Driver
- Rubber Mallet

## **Boss Grille Installation**

1. Remove Boss Grille kit from packaging. Check to see if all parts from above kit contents table are included.



 Remove plastic cover by removing 14 retaining clips (number of retaining clips may vary) with flat head screw driver (locations shown above).



3. Once cover is removed, remove the top 8 grille screws with 10mm wrench (location shown above)



 Pull upper grille forward to release upper grille clips. Once out, release 4 bottom metal clips with a flat head screwdriver by pushing down on them through hole in the plastic. Passenger side locations are shown. Repeat on driver side



- Install metal clips removed from bottom of grille in step 5 on lower boss grille bracket. Locations shown above. All should be installed the same direction. (Rubber mallet may need to be used)
- 8. <u>Install grille into truck using factory hardware</u> from Step 2, adjust boss grille bracket to desired location and tighten boss grille hardware using 7/16" wrench. Tighten all factory hardware using 10mm wrench. Reinstall plastic cover and retaining clips from Step 1. Enjoy!



5. Remove grille. Once grille is removed, lay grille on flat surface (Protect grille front face) remove 4 metal clips with screwdriver from bottom of grille and set aside.



 Install all brackets in locations shown. All brackets go on upper side of tabs. Use supplied hardware to mount all brackets. For lower bracket use bracket form step 6 and install so metal clips are facing up.

