

Nissan Titan Tailgate Handle Installation Instructions

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty
Tailgate Handle Cover	1
Pull Handle Cover	1

Tools Required:

- Rubbing Alcohol
- Clean Towel

Handle Installation

- 1. Clean and dry the vehicle thoroughly.
- 2. The vehicle surface temperature must be a minimum of 10°C (50°F).
- 3. Apply rubbing alcohol to the clean towel and wipe down the entire boxed area shown in Figure 1 on the tailgate. This will ensure proper adhesion to the vehicle.





- 4. As shown in Figure 2, remove the 3M tape from back of the tailgate handle cover.
- 5. Align the tailgate handle cover over the existing handle. **IMPORTANT: Do not to allow the adhesive surface of the panels to touch the vehicle prior to being in the correct location**. When aligned, press and hold in position for 30 seconds to ensure proper adhesion.