



1. Place leading edge in window channel. 2. Bend visor out and down at the midpoint. 3. Place the rear edge in the window channel. 4. Push and in on the middle of the visor to seat the rest of the visor in the channel.