



**SHIFTER PADDLE**  
PORSCHE PDK

PART NUMBER: 3218101B \ 3218101R

RACESENG



## SHIFTER PADDLE KIT

Shifter Paddles  
3M Tape Pads  
Alcohol Prep Pad  
Adhesion Promoter

## TOOLS REQUIRED

Small Knife

## INSTALLATION GUIDE

### Install The Double Sided Tape

1 Peel the 3M Tape Pads off the backing paper. Position the tape in the machined cavity of the shifter paddle. Once you are confident of the tape's position, go ahead and place it in the cavity. To ensure the tape is bonded well to the paddle, rub your finger and press down on the entire piece of tape. Repeat this step on the other OEM paddle.

### Prep The OEM Paddle

2 Use the supplied alcohol prep pads to clean the backside of the OEM paddle. Vigorously rub the cleaning pad on the backside of the paddle. Make sure the surface is clean.

3 Open the adhesion promoter and rub it on the backside of the OEM paddle.

### Mount The Raceseng Shifter Paddle

4 Peel the red backing layer off the 3M Tape Pad. To make this process easier, use a small knife to score only the top red layer. Make the score mark in line with the pull tab.

5 Align the Raceseng shifter paddle with the OEM paddle, once you are confident in the position of the two, press the Raceseng shifter paddle into the OEM paddle. To ensure a good bond between the paddles, squeeze the paddles together for 2-3 minutes.

6 Repeat step 4 and 5 on the opposite hand paddle.

Enjoy the drive!