



Installation Instructions

Perma Shine Polished Stainless and Black Powder Coated Front Euroguard

Part No. 7459/7659 87-06 Wrangler



Installation:

- 1) Remove Torx bolts from front Bumper assembly. 2 located on each frame member on top of the Bumper.
- 2) Place Euroguard on top of the bumper and locate the holes over existing holes in the frame.
- 3) Replace Torx bolts tighten to 45lbs torque