
# 5" OVAL BAR CURVED



#### Components: Hardware: Rubber M8 Lock M10 Lock Driver Side M8 x 25MM Step Bar -Gasket Washer Washers Hex Head Bolt Qty 4 Qty 4 Qty 8 Qty 1 Qty 4 Passenger Side M10 Flat M8 Flange Nut Step Bar -Qty 1 Qty 4 Washers Qty 8 Mount Bracket -M10 x 30 mm M8 Flat **Button Head** Qty 4 Washer **Bolts** Qty 4 Qty 8

### **Tools Required:**




# **Torque Specifications:**


For Rocker Panel Mount Installations M8 through M12 bolts and nuts are set to 15-20 ft lbs.

# Note: When installing the brackets and bars, all hardware must be left loose until all the items are attached.

- 1. Remove all contents from the package and check stainless steel tubes for any damage. Also, verify that all components and hardware listed above are included before you begin installation.
- **2.** Read installation manual and installation drawing completely. Understand all brackets and bolts before installation.
- **3.** Begin installation on the driver's side. Align **Brackets** as shown.



**4.** Align the Front and Rear Driver's Side Brackets with existing bolt and the existing hole located on the Rocker Panel.



**6.** Place the Rubber Gaskets onto the Brackets. Then place the Step Bar onto the Brackets. Each Step Bar is marked Driver and Passenger.

7. Secure the Step Bar to each Bracket using two (2) M10 x 30MM Button Head Bolts, two (2) M10 Lock Washers and two (2) M10 Flat Washers per bracket.

Tighten until the split lock washer is flat against bracket and snug. **DO NOT** over tighten and strip the threaded insert in the tube.

Repeat these steps for passenger side installation. When all hardware is in place, everything must be tightened. See Page 1 for Torque Specifications.

