



**1984-2001 JEEP CHEROKEE
FRONT BUMPER HOOP
P/N: 10-05084-4**

INSTALLATION INSTRUCTIONS

PART LIST

ITEM	DESCRIPTION	QTY.
20-05084-4	Front Hoop, Winch Bumper	1
20-72241	Hardware Pack, Front Hoop	
13-20053-Z	3/8-16 x 1" Bolt	6
13-10022-Z	3/8-16 Nyloc Nut	6
13-30012-Z	3/8 Flat Washer	12

NOTE:

This Hoop is designed as an accessory to the RCD Jeep Cherokee Winch Bumper (20-05084-1).

Front Bumper Hoop Installation Instructions

1. Place Front Bumper Hoop (20-05084-4) on Front Bumper as shown.
2. Mark and drill six 13/32" holes.
3. Install 3/8" Bolts (13-20053-Z), Washers (13-30012-Z) and Nuts (13-10022-Z). Torque bolts to 35ft. Lbs.

