

# RECON

## RECON Truck Raptor Fog Light Install

**264512RPTR**



1. Locate the mounting plates and place them on each side of the truck by the fog light opening(driver's side is picture above)
2. While lying under the front of the truck, line up the rear straight edge of the plate with the bumper support bar which is usually painted the same color as the body of the Raptor.
3. Mark the hole location in our plate with a marker or drill pilot holes in support bar that match the holes on the plate. Make sure that the beveled edge of the plate that holds the lights is lined up with the opening in the front bumper.
4. Attach the lights to the mounting plates and then fix them to the bumper support bar using the supplied self tapping metal screws.
5. Adjust the lights as needed and tighten the light mounting screws completely