

JEEP CHEROKEE 84-01 INSTALLATION INSTRUCTIONS

1. Pull straight up on shift knob.



2. Pull bezel straight up.



3. Bezel removed.



4. Bezel / boot upside down view.



5. Bezel / boot top view.



6. Pry apart two pieces of bezel.



7. Two pieces of bezel separated.



8. Drill out the fake allen security bolts (which are plastic) with a 5/32" drill bit. Screw 8-32x1/2" bolts instead. Upper half of bezel with 8-32x1/2" bolts screwed in.



9. Place upper half of bezel over top of shift boot and line up bolts with holes in shift boot.



10. Secure lower half of bezel to top half with 10-24 nuts.



11. Reinstall this assembly back into the car.

CONGRATULATIONS - YOU HAVE SUCCESSFULLY INSTALLED YOUR NEW LEATHER BOOTS!

Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product in good condition, you should take care of it. We suggest occasionally (every 4-6 week for example) applying some leather conditioner/UV protector to keep your leather from drying up in the sun and cracking.

Redline Automotive Accessories Corp. will not be held liable for any labor, incidental or consequential damages of any kind. Proceed at your own risk.

[View other gear shift knobs made by Redline Goods on our website.](#)