

CHRYSLER CROSSFIRE INSTALLATION INSTRUCTIONS

1. Push to one side and lift up on shift boot. Rotate retainer nut clockwise and down to remove the shift knob. Pull straight up on shift knob. Remove shift boot.



2. Place shift knob in shift boot.



3. Line up 4 fins on shift knob with slots inside retainer nut. Press 2 parts together. Place shift knob/shift boot/retainer nut on shift lever. Push up and rotate retainer nut counter clockwise until snug.



4. Put shift boot back in place.



Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product you should take care of it. We suggest occasionally (every 4-6 week for example) applying some leather protector to keep your leather from drying up in the sun and cracking.

Redline Automotive Accessories Corp. will not be held liable for any labor, incidental or consequence of any kind. Proceed at your own risk.

[View other gear shift knobs made by Redline Goods on our website.](#)