



SHIFT BOOT INSTALLATION GUIDE

FORD 500 / MERCURY MONTEGO INSTALLATION INSTRUCTIONS

1. Open armrest and remove t15 torx screws from hinge.



2. On a working table remove the 8 screws holding inner plastic cover to the top layer.



3. Install the leather between the two. At minimum, sandwich it between the top and the bottom surfaces, but ideally glue the leather to the top surface so prevent it from moving around when you apply your weight to the armrest. This will provide a bond that will not require occasional readjustment.



Re-install in reverse order of removal and ENJOY!

Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product in good condition, you should take care of it. We suggest occasionally (every 4-6 week for example) applying some leather conditioner/UV protector to keep your leather from drying up in the sun and cracking.