

06-10 RIO INSTALLATION INSTRUCTIONS

1. Remove both foot well kick panels, pull from the bottom out, then slide the panel towards the seats until they come free, unscrew both 10mm screws behind the panels.



2. Remove the small carpet piece behind the shifter base console, under the carpet you will find another 10mm screw, take the screw out.



3. Unscrew the shift knob.



4. Remove the ebrake handle trim from the console using a small flat screw driver, and then remove the console from the vehicle.



5. Remove the shifter boot ring from the shifter base console. !!!!!BE VERY CAREFUL NOT TO DAMAGE THE SHIFTER BOOT RING!!!!!! Separate the inner shifter boot ring from the outer shifter boot ring. Remove the stock shifter boot.



6. Re-install your new RedlineGoods genuine leather shift boot into the shifter ring and complete the installation using the above steps for re-assembly.



CONGRATULATIONS - YOU HAVE SUCCESSFULLY INSTALLED YOUR NEW LEATHER BOOTS!

Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product in good condition, you should take care of it. We suggest occasionally (every 4-6 week for example) applying some leather conditioner/UV protector to keep your leather from drying up in the sun and cracking.

Redline Automotive Accessories Corp. will not be held liable for any labor, incidental or consequential damages of any kind. Proceed at your own risk.

[View other gear shift knobs made by Redline Goods on our website.](#)