

94-98 SAAB 900S INSTALLATION INSTRUCTIONS

1. Here's what you're looking at.



2. Pull original boot out from under plastic retaining ring.



3. Detach top of boot from under the reverse lock-out part.



4. Remove shift knob (sawing it off may be necessary for original knob, which glued onto the shifter).



5. Remove original boot and plastic reverse lock-out rod



6. Slide new boot onto plastic rod backwards, making sure the end of it goes in the special indent for the boot.



7. Flip boot out again, and make sure it's on snug.



8. This is how the retaining ring fits into the center console opening.



9. Put boot on retaining ring, snap back into hole.



10. Push shift knob back on, ensuring that the numbers are lined up correctly.



ENJOY YOUR NEW LEATHER BOOTS!

Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product in good condition, you should take care of it. We suggest occasionally (every 4-6 week for example) applying some leather conditioner/UV protector to keep your leather from drying up in the sun and cracking.

Redline Automotive Accessories Corp. will not be held liable for any labor, incidental or consequential damages of any kind. Proceed at your own risk.