

REESE

You *can* take it with you.

INSTALLATION INSTRUCTIONS

CHEVY & GMC PICKUP

Product No.

37016

SMALL PARTS
PACKAGE 37431

WARNING: DO NOT LUBRICATE THREADS, BOLT FAILURE MAY OCCUR DUE TO OVER TIGHTENING.

WARNING: DO NOT DRILL OR WELD TO THIS HITCH.

IMPORTANT NOTES


USE ONLY REESE SUPPLIED OR APPROVED BOLTS, LOCKNUTS, AND WASHERS TO INSTALL THIS HITCH

TOOLS REQUIRED

21mm SOCKET

3/4" SOCKET

TORQUE WRENCH



1. Remove the 14mm bolt from the bottom of the bumper bracket on both sides of the vehicle. Align the brackets with these holes and install the two existing 14mm bolts.

2. Insert the 1/2" carriage bolts through the bolt plates and down through the remaining holes in the frame and install 1/2" serrated washer, 1/2" lock washer, and 1/2" nut. Leave all nuts loose.

3. Place center section between the brackets and insert the 1/2" black knurled bolts through the holes in the brackets. Install the 1/2" black lock washers and 1/2" black nuts. Tighten nuts until the knurled bolt heads seat against the bracket.

4. Torque all 14mm bolts to 85 ft*lb*.
Torque all 1/2" bolts to 70 ft*lb*.

Accept no compromises, choose only quality trailer hitches and towing.