



#73810

2" Red Clearance/Marker Light

*Snap-in lens, mounting bracket
Designed for 12-volt systems.*

INSTALLATION:

1. Disconnect the battery.
2. Use the angle bracket as a template to mark mounting holes for the screws.
3. Attach a lead wire to the positive (+) headlamp circuit.
4. Drill two 1/8" diameter holes and mount the angle bracket to grounded surface with two sheet metal screws.
5. Reconnect the battery.

Learn more about trailer lights on our website.