		(Sold se Drawl	Dodge C Except S parately) Dar Kit: 591	aliber SRT4	tionsPart Numbers:24769608327714524732 U-HaulDo Not Exceed Lower of Towing Vehicle Manufacturer's Rating or2000 LB (908 Kg) Max Gross Trailer Weight200 LB (908 Kg) Max Tongue Weight
Hitch Shown In Proper Position				l	Wiring Access Location: PC1, PC2
Equipment Required: Fastener Kit: 24769F Wrenches: 15/16 Fasteners typical both sides					
1	Qty. (4)	Hex Bolt 5/8-11 X 4	3	Qty. (4)	Hex Nut 5/8-11
2	Qty. (4)	Lock Washer 5/8			

1. Place 5/8 bolts into bushing from the outboard side of the frame rails. Leave flush with the inboard frame rail.

2. Raise hitch into position and push 5/8 bolts through brackets to support hitch.

3. Attached remaining fasteners as shown.

Tighten all 5/8-11 fasteners with torque wrench to 100 Lb.-Ft. (136 N*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

Reese Towpower products are your right choice if you need quality and reliability.