Installation Instructions

CHEVROLET SILVERADO PICKUP **GMC SIERRA PICKUP**

Part Numbers:

41932

81587 96932

Wiring Access Location: PU3

FACTORY INSTALLED BUMPER

BRACKET--TYPICAL BOTH SIDES

VEHICLES W/ AMBER TURN SIGNALS AND FACTORY BUMPER

NOTE!-FACTORY INSTALLED STEEL STEP BUMPER AND BRACKETS MUST BE USED IN CONJUNCTION WITH HITCH. 00

Do Not Exceed Lower of Towing Vehicle Manufacturer's Rating or Max Gross Max Tongue Hitch type Trailer WT (LB) WT (LB) Weight Distributing 14,000 (6356 Kg) 1400 (636 Kg)

Weight Carrying 12,000 (5448 Kg) 1200 (545 Kg)

Ball Mount


Hitch Shown In Proper Position

Equipment Required:

Fastener Kit: 41932N Wrenches: 7/8", 21mm **Drill Bits: NONE**

NOTE!-FACTORY INSTALLED STEEL STEP BUMPER AND BRACKETS

MUST BE USED IN CONJUNCTION WITH HITCH.



1	Qty. (6)	1/2"-13 X 1-3/4" GR 5 CARRIAGE BOLT	4	Qty. (6)	HEX NUT
2	Qty. (2)	1/4" X 1-1/2" X 3" BLOCK	(5)	Qty. (4)	1/4" X 1-1/2" X 2" BLOCK
3	Qty. (6)	CONICAL TOOTHED WASHER			

- 1. Remove existing M14 bolts from end of each frame rail.
- Lift receiver into position, locating rearmost slots in receiver under existing weldnuts in vehicle frame. 2.
- 3. Reinstall existing M14 bolts through receiver and frame into existing weldnuts.
- Install remaining fasteners as shown. 4.

Tighten all M14 fasteners with torque wrench to 115 Lb-Ft . (156 N*M)

Tighten all 1/2" GR 5 fasteners with torque wrench to 75 Lb.-Ft. (156 N*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.