

Please follow these basic installation guidelines:

1. **DO NOT BEND!** Remflex gaskets are designed to withstand clamping force and incredible heat, but not bending. If you bend them, they will break!

2. **Do not over tighten.** When properly installed the flange should be tightened evenly. See the suggested torque range.

3. **Longer bolts aren't necessary.** Though Remflex are thicker than other gaskets, standard length bolts will work fine.

4. **Do not use sealers.** Silicone and other sealers cannot withstand the same temperature as Remflex gaskets, and can actually cause leaks.

Learn more about exhaust systems on our website.