

## READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

---

### INSTALLATION INSTRUCTIONS FOR DEAD PEDAL

Check to make sure you that have all parts listed prior to insta  
If anything is missing contact us immediately

Parts List

- (4) #8/32X5/8" Black S/S
- (1) Dead Pedal

- A. Determined what holes will be used for mounting and remove rubber grips from those holes.
- B. Place aluminum dead pedal over the top of factory unit.
- C. Drill the mounting holes using a 1/16" drill bit.
- D. Install dead pedal with the supplied black truss head screws.

