



Driven to improve excellence.

## Retractable Tow Hook Assembly

### READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

These tow hook have been designed to be used on both sides of the car and can be mounted vertically or horizontally. Make sure that you have all parts required before installation. If you are missing anything, please call us immediately.



#### Parts List:

- (1) Tow hook assembly
- (2) Tow stickers
- (1) Extension Spring MC 9654K215
- (1) 3/8 - 24 x2.24 Bolt MC 91257A660
- (1) 3/8 - 24 Nut MC 95615a150



Mount the tow hook assembly into the factory bumper shock location using the factory shock flange and hardware on all 1989-1998. Porsche 964/993. If this assembly is being used for a custom application, other brackets and fabrication may be required.



Cut a slot into bumper allowing tow hook to be extracted without rubbing on tow hook finish.