

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

Kit Includes:
2 Tow Stickers
1 Tow Hook



Mounts on top of factory bumper shock attachment point on all 1983-1991 944's using factory hardware.