

Smugglers Box Cover Switch Mount

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

This kit is designed to be used with Rennline remote pull cables.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

- (1) Cable Bracket- EL20_cbl_brkt
- (2) Fender Washers MC90313A104
- (2) Button Head Screws 10-32 5/8" MC92949a267
- (2) Nuts 10-32 Nyloc - MC90101A225
- (2) Rubber Spacers - MC90131A102
- (2) On/Off indicators - MC9688K271

