

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

(1) Pedal Board face plate (Black or Silver)



1. Remove factory floor mat from car.
2. Remove plastic nut by rotating it counter clockwise, as shown in figure 1.
3. Install pedal board
4. Reinstall plastic nut as shown in figure 2
5. Reinstall floor mat or track mat as shown in figure 3.

