

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Part List:

- (1) Mounting Bracket - P/N - PM08
- (1) P/N - PM01
 - Aluminum Ball
 - Magnetic Pad Assembly
 - Steel pads
- (1) Black S/S Socket Head Screw - 10/32 x .5" - MC91255A265
- (1) Round Head Screw - #10 x .5" - MC 90356A285



1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Determine which side (Driver or Passenger) you will be installing your mount on and remove the corresponding center console pad. To remove the pad, grab the back edge and pull away from the center console. (Photo 1)
3. Install the metal bracket over the top of the plastic tab and attach to the hole in the console using the supplied screw.
4. Re-install the center console side panel
5. Remove the lock nut from the magnetic pad assembly, and install the nut over the top of the aluminum ball with the threads pointing out.
6. Snap the magnetic pad assembly over the aluminum ball and secure by tightening the lock nut.
7. Attach the metal plate to your phone case or phone. If you have a thick phone case, we recommend applying the metal plate to the outside of the phone case for maximum magnetic pull.
8. Attach the phone to your mount.
9. Enjoy your new Rennline product.

Photo 1



Photo 2



Photo 3



Photo 4

