

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.



Part List:

- (1) Mounting Bracket - P/N - PM11
  - Pre-applied double-sided adhesive
- (1) P/N - PM01
  - Aluminum Ball
  - Magnetic Pad Assembly
  - Steel pads
- (1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Determine which side of the center console you will be installing your mount on, and locate and remove the screw in the middle of the carpet pad at the front of the footwell against the console using a Torx T25 bit. (Photo 1)
  - On cars with a Bose system, the subwoofer cover will need to be removed if installing on the passenger side. Locate the screw inside of the vent at the top of the subwoofer box and remove it. (Photo 2)
3. Pull carpet pad forward and let hang in footwell. Locate two Torx T20 screws that hold the radio side-pad in and remove them.
4. Carefully slide radio side-pad out towards the shifter. It will take some force - it is held in by a number of clips. (Photo 3)
5. Install PM11 bracket with double-sided adhesive as shown in Photo 4. Be sure to push the bracket as far towards the face of the radio side-pad as possible before sticking the adhesive. (Photo 4)
6. Reinstall side-pad, carpet-pad, and all associated screws in reverse order of removal.
7. Remove the lock nut from the magnetic pad assembly, and install the nut over the top of the aluminum ball with the threads pointing out.
8. Snap the magnetic pad assembly over the aluminum ball and secure by tightening the lock nut.
9. Attach the metal plate to your phone case or phone. If you have a thick phone case, we recommend applying the metal plate to the outside of the phone case for maximum magnetic pull.
10. Attach the phone to your mount.
11. Enjoy your new Rennline product.

Photo 1



Photo 2



Photo 3



Photo 4



Photo 5

