

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. Accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

Rennline M12 Eccentric Lock Kit

Check to make sure that you have all parts listed prior to installation.

Parts List:

- (1) M12x90mm Bolt MC91310A740
- (1) M12x1.75 Nut MC98498A100
- (2) M12 Washer MC98035A107
- (2) P/N S40 Eccentric Locks

- Step 1 - Remove factory Eccentric Bolts
- Step 2 - Install Rennline Eccentric locks as shown below
- Step 3 - Torque bolts to 75 ft-lbs.
- Step 4 - Align car

Sub frame
(Top View)

